REPLACEMENT PARTS LISTING


MAIN PARTS LIST (reference Figure #3)

for the MegaSpray Reservoir Module P735-B

The following parts are common to the MegaSpray Reservoir Module

				. <u>9 - </u>	,		
	Part Number		Description -or- Part Name		Part Number		Description -or- Part Name
1	RES031	1	RESERVOIR, Tank:	16	OUT011	1	OUTLET, Bulkhead:
2	COV020	1	COVER, Tank:	17	RG0082	1	RING, "O" type: seal
3	BRK096	4	BRACKET, Mounting:	18	NUT170	1	NUT, Special: jam
4	RGO013	6	RING,"O" type:seal	19	FIT062	1	FITTING, Plug: pipe
_ 5	NUT107	4	NUT,Jam:locking	_20	OUT010	1	OUTLET, Drain:
6	NUT058	2	NUT, Hexagon: jam	21	RG0051	1	RING, "O" type; seal
7	RGO030	2	RING, "O" type: seal	22	NUT062	1	NUT, Hexagon: jam
8	INL026	1	INLET, Sight:	23	FIT076	2	FITTING, Nut:
9	PIP009	1	PIPE, Plastic: sight	24	FIT077	2	FITTING, Support: tub
10	OUT009	1_	OUTLET, Sight:	_25_	TUB218	1	TUBE, Plastic:
11	RG0034	1	RING, "O" type: seal	26	FIT025	1	FITTING, Adapter: cor
12	PLG026	1	PLUG, Sight:	27	TUB156	1	TUBE, Plastic:
13	FIL018	1	FILTER, Fluid:	**A	200BBD14	4 1	MegaSpray Module
14	FIT057	1	FITTING, Elbow: barb				
15	FIT073	1	FITTING, Elbow: barb	** See MAIN PARTS LIST for the MegaSpray			

^{**} See MAIN PARTS LIST for the MegaSpray Module for further breakdown of parts.




INSTALLATION, OPERATION, and TROUBLESHOOTING

DISTRIBUTION

with REPLACEMENT PARTS LISTING for the MegaSpray Module Model P-730-B & P-735-B Supercedes P-730 and P-735



P.O. Box 5303, ROCKFORD, IL ● 61125 2511-20TH ST., ROCKFORD, IL ● 61104 TEL: 815-226-8090 ● FAX: 815-226-9250 E-MAIL: SALES@LSPIND.COM



SUPPLEMENTAL INSTRUCTIONS

These **INSTRUCTIONS** rely heavily on information found in supplemental Instruction Sheets. Before starting, make sure that the **INSTALLATION**, **OPERATION**, and **TROUBLESHOOT**-ING Instructions with the following subtitles are available for

for the MegaSpray__Model No. P135-B

Describes the operation and maintenance of the MegaSpray.

The MegaSpray provides the lubricant spraying function.

for the On/Off Manifold_Model P934

Describes using the ON/OFF MANIFOLD to split-up and control the **DISTRIBUTION LINES**.

for the (appropriate ACTUATOR chosen)

Describes the device chosen to actuate the UNIT. There are a variety of these. You must have one to operate the **UNIT**, and along with it, must have it's Instruction Sheet.

If any of the Instruction Sheets called for above are missing, they must be located. If they cannot be found, request replacements for whichever is missing from L.S.P.

the entire MegaSpray Module

These supplemental Instruction Sheets will be necessary for proper installation and maintenance of the UNIT, always keep them attached to these Instructions.

These Instructions cover three different Model Units. Most of the data herein pertains to all; however, should a paragraph only pertain to specific Models, that paragraph will begin "Only for Model No...." and give the respective Model Number(s) for that UNIT.

10/2012

INSTALLATION INSTRUCTIONS

A. Installing the Actuator
See the Instruction Sheet for the ACTUATOR you have chosen to use. Follow the given INSTALLATION INSTRUCTION supplied with that **ACTUATOR**.

If you have no ACTUATOR, see the ACCESSORIES Section of the **MegaSpray** Instruction Sheet for a list of those available.

B. Installing the UNIT
See the MegaSpray's Instruction Sheet under the heading Installing the MegaSpray.

1. Locating the UNIT

Consider the suggestions given for the **MegaSpray** under the similar heading. The same applies for this **UNIT**.

2. Mounting the UNIT Only for Model No. P730. Drill and tap for four 3/8-16 screws on center with the holes in the MOUNTING PLATE.

Use the **SPACING WASHERS** supplied to keep the **PLATE** away from the mounting surface (done to relieve for protrusions on the back side of the **PLATE**).

Insert screws through the holes and washers, and torque securely into the tapped holes.

Only for Model No. P735. The UNIT can be simply set into place on the feet provided by the RESERVOIR, or can be mounted on a wall using the holes provided in the tabs

For wall mounting; drill and tap for two 1/4" screws on center with holes in **Reservoir**. Insert screws and torque.

C. Installing the Fluid Supply
Only for Model No. P730. See the MegaSpray's Instruction
Sheet under the similar heading. Use the appropriate area in the instructions (for using a RESERVOIR or PUMP).

Only for Model No. P735. A RESERVOIR is included with this **UNIT**, which is simply filled with the lubricant.

D. Installing Air Supply
See the MegaSpray's Instruction Sheet under the same heading. The same principles apply for this UNIT.

The AIR FILTER/REGULATOR/LUBRICATOR which is recommended in the Instruction is included with this UNIT. The AIR SUPPLY is to be connected at it's AIR INLET PORT as illustrated.

E. Installing the Distribution System

See the **MegaSpray's** Instruction Sheet under the same heading. The same principles apply for this **UNIT**.

OPERATING INSTRUCTIONS

All operation concerning the spraying of the lubricant is the same as described in the **MegaSpray's OPERATING INSTRUCTION**. Follow the instructions given therein.

All operation concerning the control of the **UNIT** is described in the **OPERATING INSTRUCTIONs** for the chosen **ACTUATOR**. Follow the instructions given therein.

TROUBLESHOOTING

See the appropriate TROUBLESHOOTING INSTRUCTIONS for the MegaSpray or ACTUATOR depending on the type of problem to be solved

Use the REPLACEMENT PARTS LISTING at the left and at the back for parts not found in the other Instructions.

REPLACEMENT PARTS LISTING


MAIN PARTS LIST (reference Figure #1) for the MegaSpray Modules

Key <u>No.</u>	Part Number	No. Pcs	Description -or- Part Name
1	PLT068	1	PLATE, Mounting:
2	WAS006	4	WASHER, Plain: 1/4"
3	SCR080	4	SCREW,Cap:
4	FIT070	1	FITTING, Elbow:
5	TUB305	1	TUBE,Copper:
6	FIT071	1	FITTING,Adapter:
7	WAS001	2	WASHER,Lock:#10
8	SCR023	2	SCREW,Cap:
9	459BRK03	1	BRACKET ASSY:union
10	ADP068	1	ADAPTER, Mounting:
11	NUT063	2	NUT,Jam:special
12	BRK044	1	BRACKET,Mount:
13	SCR075	2	SCREW,Cap:
14	WAS003	2	WASHER, Plain: 1/4"
15	SCR078	4	SCREW,Cap:
16	WAS016	4	WASHER, Plain: 3/8"
17	SPC017	4	SPACER, Mounting:
Α	240EJT02	1	MegaSpray Unit
В	290MAN10) 1	On/Off Manifold
С	REG019	1	Air Regulator/Oiler

Supplemental Parts Listings

The parts below are further broken down in Supplemental Parts Listings and Illustrations

	Part Description	Listing Reference
Α	MegaSpray	See Instruction Sheet for the
		MegaSpray Model P135-B
В	Manifold	On/Off Manifold Model P934
		See the Parts Listing "B" and Figure #2
С	Air Handling	See the Parts Listing "C" and Figure #2



To eliminate redundent parts in the drawing we have used the 2 port Manifold in place of the 4 port manifold. Just one valve system is shown in place of three valve systems.

PART LIST "B"

290-MAN-10 Manifold Assembly

(reference Figure #2)

Key No.		No. Pcs	Description -or-Part Name
1	SCR-060	3	SCREW, Button Head
2	MLD-051	3	MOLDING, Knob: small
3	SCR-086	6	SCREW, Cap: soc hd.
4	PLT-071	3	PLATE, Retainer: small
5	RGB-032	3	RING, Backup: solid
6	RGO-057	3	RING. "O": seal.
7	STM-002	3	STEM, Valve: on/off.
8	HSG-227	1	HOUSING, Valve.
9	SET-036	6	SEAT, Valve: on\off
10	BAL-052	3	BALL, Valve: on/off.
11	OUT-014	3	OUTLET, Valve: 1/4 comp
12	FIT-017	3	CAP, 1/4 comp.
13	FIT-021	1	FITTING, Adapter

